

Three Ways to Remodel Your Bathroom



| <u>Frequently asked Questions?</u> | <u>Conventional Remodeling</u> | <u>Reglazing or Refinishing</u> | <u>Luxury Bath System</u> |
|---|--|---|--|
| How long does it take? | Takes up to two weeks to complete. | Usually completed in one day, however takes up to one week to fully cure. | Can be completed in less than a day. |
| How much does it cost? | Average cost to remodel a bath enclosure is \$9,641 according to the 2003 edition of <i>Qualified Remodeler</i> . | The cost to spray bathtub and tile in White is around \$800-\$900. | Fraction of replacement cost. White tubliner and wall systems start at \$1,895. |
| What is involved? | Bathroom is gutted down to the studs. After debris is removed and plumbing is modernized, new dry wall or green board is applied and new bath fixtures are installed. | Sprayer brings a gallon of paint into bath area and after surfaces are prepared and masked off, the paint is applied with a compressor and gun. | Certified Luxury Installer enters bath with a custom fitted tubliner and three oversized wall panels along with a new chrome plated brass drain and overflow cover. Acrylic liners are installed right over existing fixtures eliminating demolition and minimizing dust and debris. |
| What contractors are needed to do the work? | Requires several specialty contractors including, plumbers, carpenters, tile installers, painters, electricians, etc. | Can be sprayed by one technician wearing an OSHA approved respirator and full body protection suit. | One Certified Luxury Bath Installer. |
| What hazards are involved? | Damage to flooring, walls and other furnishings are possible during demolition. Antiquated plumbing may become an issue. | Toxic odors from spraying may create health issues. Overspray may damage surrounding fixtures. Peeling paint may be ingested by infants and toddlers. | None |
| Is there any mess involved? | Debris must be totally removed from bath, and homeowner may incur added expenses to have heavy and oversized fixtures hauled away. Construction dust can leave residue on floors and furniture | Towels and rags with paints and solvents need to be disposed of as outlined in the EPA's hazardous materials handbook. | Scrap acrylic is easily removed by Luxury Bath installer and recycled eliminating costly waste and helps to save the environment. |
| What are the results? | Homeowner will still have porous grout Lines around the tile to scrub regularly. | Painted surface must be maintained with specialized cleansers to avoid peeling and dulling of the painted surface. | High gloss acrylic bath enclosure in non-porous and maintenance-free and is easily cleaned with dish soap and water. |